



Projector Controls



TO ACTIVATE:

Touch the three bars at the upper right-hand corner of your screen



SOURCE SELECTION:


Select **Room PC** to activate the projector/screen



VOLUME CONTROLS:

Use the Volume Controls at the bottom of the screen as needed

Projector Controls



TO ACTIVATE:

Touch anywhere on the Touch Panel screen

SOURCE SELECTION:

Select **Room PC** to activate the projector & screen

VOLUME CONTROLS:

Use the Volume Controls at the bottom of the screen as needed